

# Distribution Centers

- Various modular distribution configurations
- Complete front access
- Integrated Cordex™ system controller
- Integrated shunt and LVD options
- AM plug-in breaker, GJ breaker and GMT fuse options



Vista Two Tier UDC

## Distribution Panel Overview

	Part Number	Fuse Position	Fuse Type	Breaker Position	Breaker Type	Capacity	Mounting	Front Access	RU	Additional Options
Universal Distribution Centers	020-584-20	16*	TPS*	16	AM Plug-In	400A	19/23	Partial	4	Controller, LVD, Shunt, Batt Disconnect
Vista Distribution Centers	020-645-20	20-24* 10	TPS* GMT	20-24	AM Plug-In**	800A	23	Yes	7	Controller, LVD, Shunt
	020-646-20	40-48* 10	TPS* GMT	40-48	AM Plug-In**	1000A	23	Yes	9	Controller, LVD, Shunt
	020-635-20	80-96* 10	TPS* GMT	80-96	AM Plug-In**	2000A	23	Yes	17	Controller, LVD, Shunt
<b>Modular Distribution Tier Options</b>										
Single Voltage:	24 Position AM plug-in (TPS plug in available) 20 Position AM plug-pn w/ 600A LVD 3 Position GJ 3 Position GJ w/ 600A LVD									
Dual Voltage:	12x Primary and 10x secondary (AM plug-in) 16x Primary and 6x secondary (AM plug-in) 8x Primary (w/ LVD) and 10x secondary (AM plug-in) 12x Primary (w/ LVD) and 6x secondary (AM plug-in)									
Notes: * TPS Fuses with AM plug-in breaker cartridges may be used as alternative to breakers ** Compatible with multiple pole AM plug-in breakers (110 to 250A)										



Universal Distribution Center