



NOTE:

Before applying power, verify power supply rating is matched to AC input utility. Verify a low-resistance ground is installed in accordance with the NEC (refer to CableUPS Power Supply technical manual for details).

Pre-Service Connection Procedure (reference callouts at right)

1. Verify the Inverter Module's battery breaker is OFF.




WARNING!

Verify battery voltage, cable color, connection and polarity are correct before proceeding.

2. Connect battery cables to battery input connector.
3. Install temperature probe cable.
4. Insert Local/Remote Indicator (LRI) cable (optional).
5. Connect status monitoring connectors, including tamper switch (if installed).
6. Verify SPI switch is in "ALT" position.
7. Connect the SPI (network load) to the Output 1A connector.
8. Connect an auxiliary load (e.g., fan) to the Output 1B connector (optional).
9. Switch the Inverter Module's battery breaker ON.
10. Turn on AC breaker (located on enclosure) and verify correct (per unit's nameplate voltage) utility voltage at outlet; if correct, plug in line cord to the utility outlet.
11. Verify no alarms are present (it may take up to 60 seconds for alarms to clear).
12. Once unit is running on line voltage, perform a self-test by simultaneously pressing the DOWN arrow key and ENTER key. Wait for Self-test completion before proceeding. **Note: If the unit is operating from batteries, the self-test will not initiate.**
13. Perform this inverter test procedure:
 - a.) Turn AC input breaker OFF.
 - b.) Verify unit transfers to "Inverter" mode.
 - c.) Turn AC input breaker ON.
 - d.) Verify unit transfers back to utility.

In-Service Connection Procedure

1. Verify Service Power Inserter (SPI) toggle switch in ON position (not ALT).
2. The unit is now in service. Download the Technical Manual at: www.alpha.com.



Product and Technical Support

General product information/customer service (7 AM to 5 PM, Pacific): **1-800-863-3930**

Technical support, (7 AM to 5 PM, Pacific or 24/7 emergency): **1-800-863-3364**

Notice of FCC Compliance

Per FCC 47 CFR 15.21:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Per FCC 47 CFR 15.105:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

For more information visit www.alpha.com

United States Bellingham, Washington Tel: 360 647 2360 Fax: 360 671 4936
 Canada Burnaby, British Columbia Tel: 604 436 5900 Fax: 604 436 1233